



DWG No	Description	Part Code	Qty	DWG No	Description	Part Code	Qty	DWG No	Description	Part Code	Qty
1	PUSH TABLE	057-0101	1	86	REAR MOUNT PLATE	057-0164	1	153	SCREW	F-TFPX-4-8-ST-BO	1
2	SCREW	F-SPHPZ-M5-12-ST-BO	8	87	FRONT ROTATE BLOCK	057-0165	1	154	LOCK PIN	057-0236	1
3	GUIDE RAIL (A)	057-0102	1	88	FRONT MOUNT PLATE	057-0166	1	155	SPRING	057-0237	1
4	SPRING	057-0103	1	89	DUST CHUTE	057-0167	1	156	PIN CAP	057-0238	1
5	BOLT	F-SHCS-M5-12-ST-BO	5	90	BLADE GUARD STOP (REAR)	057-0168	1	158	EXTENSION TABLE PAD	057-0239	1
6	INSERT PLATE	057-0104	1	91	BLADE GUARD STOP (FRONT)	057-0169	1	159	BASE LABEL	057-0240	1
7	INSERT PLATE LOCKING PLATE	057-0105	1	92	BLADE GUARD PLATE SPRING	057-0170	1	160	LOGO LABEL	057-0241	1
8	NUT NYLOCK	F-NNIF-M5-ST-BO	10	93	FLAT WASHER	057-0171	5	161	BEVEL LABEL	057-0242	1
9	BOLT	F-SHCS-M6-16-ST-BO	1	94	LOWER BLADE GUARD PLATE	057-0172	1	162	NAMEPLATE	057-0243	1
10	SPRING WASHER	F-SWA-M6-ST-BO	1	95	AXIAL SCREW	057-0173	2	163	BUSH	057-0244	1
11	SELF-TAPPING SCREW	F-TFPX-4.8-10-ST-BO	2	96	DUST TUBE	057-0174	1	164	BEVEL GEAR	057-0319	1
12	LEFT EXTENSION TABLE	057-0106	1	97	MOUNT PLATE	057-0175	1	165	MOTOR ASSEMBLY 230V	057-0305	1
13	EXTENSION ROD	057-0107	2	98	NUT NYLOCK	F-NNIF-M8-ST-BO	11	166	HOSE RETAINER	057-0320	1
15	NUT	F-NSF-M6-ST-BO	6	99	WASHER	057-0176	3	167	BLADE GUARD	057-0306	1
16	GUIDE RAIL (B)	057-0108	1	100	LOCKING PAD	057-0177	1	168	ANGLE GAUGE	057-0307	1
17	SCREW	F-SPHPZ-M6-35-ST-BO	8	101	LOCKING SCREW	057-0178	1	169	GEARBOX ASSEMBLY	057-0308	1
18	GUIDE ROLLER	057-0109	4	102	BEVEL LOCKING HANDLE	057-0179	1	170	HOLD DOWN CLAMP	057-0309	1
19	SHOULDER SCREW	057-0110	4	103	ANGLE FIX SCREW	057-0180	1	171	RIP FENCE ASSEMBLY	057-0310	1
20	TABLE	057-0111	1	104	ANGLE INDICATOR	057-0181	1	172	WHEEL FRAME	057-0311	1
21	LEFT EXTENSION TABLE LOCKING SPRING	057-0112	2	105	ANGLE INDICATOR FRAME	057-0182	1	173	WHEEL ASSEMBLY	057-0312	1
22	LOCKING LEVER	057-0113	2	106	BRACKET - DRIVING ROD	057-0183	1	176	HEIGHT ADJUSTMENT ASSEMBLY	057-0315	1
23	INDICATOR	057-0114	1	107	BEVEL GEAR	057-0184	2	177	ASSEMBLY SCREW KIT	057-0321	1
24	FLAT WASHER	F-W-M4-ST-BO	9	108	SCREW	F-SPHPZ-M4-20-ST-BO	1	213	THUMB WHEEL	057-0256	6
25	SPRING WASHER	F-SWA-M4-ST-BO	12	112	SPLIT PIN	F-SP-3-20-ST-BO	2				
26	SCREW	F-SPHPZ-M4-8-ST-BO	5	120	BEVEL GEAR PAD	057-0195	1				
27	NUT NYLOCK	F-NNIF-M6-ST-BO	12	121	ELEVATION CRANK SHAFT	057-0196	1				
28	FIXING HOLDER	057-0115	1	122	SPLIT PIN	F-SP-2.5-20-ST-BO	1				
29	CARRIAGE BOLT	057-0116	1	123	CABINET	057-0197	1				
30	EXTENSION TABLE LOCKING HANDLE	057-0117	1	124	CARRIAGE BOLT	057-0198	1				
31	PLATE	057-0118	2	125	SPACER	057-0199	1				
32	CLAMPING PLATE	057-0119	2	126	BLADE WRENCH (A)	057-0200	1				
33	LOCKING BLOCK SPRING	057-0120	2	127	BLADE WRENCH (B)	057-0201	1				
34	FRONT LOCKING FOR EXTENSION TABLE	057-0121	1	128	POWER CORD 230V (UK)	057-0202	1				
35	REAR LOCKING FOR EXTENSION TABLE	057-0122	1	129	CABLE CLAMPS	057-0207	2				
37	FRONT RAIL	057-0314	1	130	SCREW	F-TFPX-4.2-16-ST-BO	13				
40	REAR RAIL	057-0313	1	131	SWITCH CLAMP	057-0208	1				
42	RIGHT EXTENSION TABLE	057-0129	1	132	CORD CLAMP PLATE	057-0209	2				
43	HEX NUT	F-NSF-M5-ST-BO	6	133	SWITCHBOX	057-0210	1				
44	SCREW	F-SPHPZ-M5-20-ST-BO	1	134	OVERLOAD SWITCH 230V	057-0211	1				
45	LOCKING PLATE	057-0130	4	135	CONNECTING WIRE	057-0215	1				
46	FLAT WASHER	057-0131	4	136	CAPACITOR 230V	057-0216	1				
47	BOLT	F-SHCS-M5-16-ST-BO	4	137	SWITCH HOLDER	057-0220	1				
48	SCREW	F-TFPX-4.2-13-ST-BO	6	138	SWITCH 230V	057-0221	1				
50	SCREW	F-TFPX-3.5-9.5-ST-BO	4	139	HEX SCREW	F-HFB-M6-16-ST-BZP	2				
51	COIL SPRING	057-0133	2	140	GEAR RACK	057-0225	1				
52	CARBON BRUSH (PR)	057-0134	2	141	SCREW	F-HFB-M8-16-ST-BZP	2				
53	BRUSH HOLDER	057-0135	2	142	BASE PLATE	057-0226	1				
58	SPRING WASHER	F-SWA-M5-ST-BO	18	143	CABLE CLAMPS	057-0227	2				
68	DOUBLET NUT	057-0150	1	144	90 ANGLE ADJUSTMENT WHEEL	057-0228	1				
77	MOTOR BRACKET	057-0157	1	145	45 ANGLE ADJUSTMENT WHEEL	057-0229	1				
78	BLADE GUARD	057-0158	1	146	CORD GUARD	057-0230	1				
79	INNER FLANGE	057-0159	1	147	PUSH STICK	057-0231	1				
81	OUTER FLANGE	057-0160	1	148	RIVING KNIFE BRACKET	057-0232	1				
82	BLADE BOLT	057-0161	1	149	RIVING KNIFE	057-0233	1				
83	REAR ROTATE BLOCK	057-0162	1	150	RIVING KNIFE CLAMP	057-0234	1				
84	CROSS-SCREW	F-SCHPZ-M5-18-ST-BO	9	151	HEX SCREW	F-HFB-M6-25-ST-BZP	4				
85	SET SCREW	057-0163	1	152	INSERT PLATE LOCK	057-0235	1				

evolution[®]

RAGE5-S
Multipurpose Table Saw

Service Parts List

057-0001.01